

NOTES:

- Use 1/2" wide felt expansion material at 60 ft. O.C. and each end of pour, install deep score at 10' O.C.
- Use #4 12" epoxied dowels @ 18" O.C. at each end of pours
- Asphalt concrete patches shall be with 3/8" max med hot mix.
- For guidance on installation of valley gutters in Barron Park, refer to the City of Palo Alto's "Barron Park Drainage and Street Design Guidelines".

Rev	Ву	Date		Approv	ed by: ح	
0	HQN	10/18/06	Valley Gutter		nd 2	
1	MMN	02/21/14	Asphalt Concrete Streets	PE No.	72158	
2	RTN	08/10/17			01/10/18	
			City of Palo Alto Standard	Dwg	1224	
Scale: NTS			City of Palo Alto Standard	No.	132A	